




Index No	Part Ref	Description	Qty
A	6154600400	REGULATOR ASSEMBLY	
3		REGULATOR	1
4		O-RING 8.1x1.6	1
5		O-RING 8x1	1
6		SPRING RING WR9	1
7		VALVE STEM	1
8		O-RING 2x1	1
B	2050546343	VALVE KIT	1
9		TIP VALVE	1
10		SPRING	1
C	2050547893	FRONT PLATE ASSEMBLY	
25		FRONT PLATE	1
26		PIN SPRING 3x4	1
27	6157580520	BEARING 10x26x8	1
28		WASHER	1
D	2050547933	REAR PLATE ASSEMBLY	
26		PIN SPRING 3x4	1
33		REAR PLATE	1
34	6157581380	BEARING 8x22x7	1
E	2050547943	MOTOR ASSEMBLY	
C	2050547893	FRONT PLATE ASSEMBLY	1
D	2050547933	REAR PLATE ASSEMBLY	1
29	6154261240	ROTOR	1
31	2050547803	BLADES (SET OF 4)	1
32	6154001510	CYLINDER	4

Index No	Part Ref	Description	Qty.
F	2050546413	SMALL PARTS KIT	
6		SPRING RING WR9	1
8		O-RING 2x1	1
12		O-RING 27x2	1
14		NEEDLE 2.5x11.8	1
17		O-RING 17x2	1
21		O-RING 10.5x1.5	1
39		RING	1
40		SPACER	1
41		O-RING 15.6x1.78	1
G	2050547923	TUNE-UP KIT CP3000-5..., CP3030-5..	
2		SEAL	1
16		FELT	1
22		PAPERGASKET	1
31	2050547803	BLADES (SET OF 4)	1
1	2050547773	HANDLE ASSY (incl. Part # 15)	1
11	6155740650	AIR CONTROL RING 18 000 RPM	1
	6155740610	AIR CONTROL RING 20 000 RPM	1
13	2050541493	SAFETY LEVER	1
15		REAR CAP	1
18	2050542533	INLET ASSY	1
19	6153212410	INSERT (Incl. Item #20)	1
23	6157301890	NUT	1
24	6155653230	MOTOR HOUSING	1
30	6156080510	ROTOR NUT	1
35	6154600440	BLOCK PLATE	1
36	6156731450	COVER	1
37	6155230230	COLLET HOLDER SIAL.200	1
38	6156071540	COLLET NUT SIAL 200	1
39	6158727980	WARNING STICKER	1

	2050544623	EC declaration
	6159948750	Safety instructions
	2050543813	Operator's manual

Spare parts without part number are not sold separately

2050548113 Rev. 3

Recommended collets

1/8" (2,4 to 3,2mm) 200 series	6155260610
2-1/4" (5,2 to 6mm) 200 series	6155260620
1/4" (5,55 to 6,35mm) 200 series (included)	6155260630
5/16" (7,2 to 8mm) 200 series	6155260640
3/8" (8,7 to 9,5mm) 200 series	6155260650