

# PNEUMATIC OIL EXTRACTOR - SPARE PARTS


**53380000**

REF	PART NO	DESCRIPTION	QTY
1	533800-01	Bolt	2
2	533800-02	Wheel	2
3	533800-03	Tank	1
4	533800-04	Swivel Wheel	2
5	533800-05	Washer	2
6	533800-06	Nut	2
7	533800-07	Elbow	2
8	533800-08	Ring	2
9	533800-09	Tube	1
10	533800-10	Ball Valve	1
11	533800-11	Discharging Hose	1
12	533800-12	Valve Body	1
13	533800-13	O-ring	1
14	533800-14	O-ring	1
15	533800-15	Steel Ball	1
16	533800-16	Spring Lock Washer	1
17	533800-17	Screw	1
18	533800-18	O-ring	1
19	533800-19	Shaft	1
20	533800-20	O-ring	1
21	533800-21	Valve Body	1
22	533800-22	O-ring	1
23	533800-23	Bolt	1
24	533800-24	O-ring	1
25	533800-25	Knob	1
26	533800-26	Valve Plug	1
27	533800-27	O-ring	1
28	533800-28	Ball Valve	1
29	533800-29	Muzzle	1
30	533800-30	Valve	1
31	533800-31	Gauge	1
32	533800-32	Rubber Shroud for Gauge	1
33	533800-33	Y-Elbow Adaptor	1
34	533800-34	Elbow Adaptor	1
35	533800-35	Nut	1

REF	PART NO	DESCRIPTION	QTY
36	533800-36	Valve Seat	1
37	533800-37	Complete Muffler	1
38	533800-38	Probe Container	1
39	533800-39	Valve	1
40	533800-40	Ball Valve	1
41	533800-41	Plug	1
42	533800-42	Suction Hose, Complete	1
43	533800-43	Protector - Suction Hose	2
44	533800-44	Ball Valve	1
45	533800-45	Elbow Adaptor	1
46	533800-46	Link	1
47	533800-47	O-ring	2
48	533800-48	Flexible Probe 5x700	1
49	533800-49	Flexible Probe 6x700	1
50	533800-50	Flexible Probe 7x1000	1
51	533800-51	Flexible Probe 8x700	1
52	533800-52	Metal Probe 5x700	1
53	533800-53	Metal Probe 6x700	1
54	533800-54	Connector (VW)	1
55	533800-55	O-ring	2
56	533800-56	Connector (BMW)	1
57	533800-57	O-ring	1
58	533800-58	Spring Lock Washer	1
59	533800-59	O-ring	1
60	533800-60	Knob	1
61	533800-61	Seat	1
62	533800-62	O-ring	2
63	533800-63	Adjustable Steel Tube	1
64	533800-64	Ball Valve	1
65	533800-65	Rotor	1
66	533800-66	O-ring	2
67	533800-67	Oil Collection Bowl	1
68	533800-68	Nut	1
69	533800-69	Plastic Filter	1

